

Installation Guide for CYME, CYMCAP and CYMGRD

This manual is applicable for the following software and versions: CYME: Versions 7.0, 7.1 CYMCAP: Version 6.2 CYMGRD: Version 6.5



© Copyright CYME International T&D Inc.

All Rights Reserved

No part of this publication may be reproduced, or transmitted in any form or by any means without the written permission of CYME International T&D.

Possession or use of the CYME software described in this publication is authorized only pursuant to a valid written license agreement from CYME.

CYME makes no warranty, either expressed or implied, including but not limited to any implied warranties of merchantability or fitness for a particular purpose, regarding these materials and makes such materials available solely on an "as-is" basis.

CYME International T&D reserves the right to revise and improve its products as it sees fit. The information in this manual is subject to modification without notice.

While every precaution has been taken in the preparation of this manual, CYME assumes no responsibility for errors or omissions, or for damages resulting from the use of the information contained herein.

CYME International T&D Inc. 1485 Roberval, Suite 104 St. Bruno QC J3V 3P8 Canada

Tel.: (450) 461-3655 Fax: (450) 461-0966 Canada & United States: Tel.:1-800-361-3627

Internet : www.eaton.com www.cyme.com E-mail: cymesupport@eaton.com

Other Trademarks: The names of all products and services other than CYME's mentioned in this document are the trademarks or trade names of the respective owners.

Contents

1 – Introduc	ction	7
Rec	ommended System Requirements	7
	Hardware Requirements	7
	Software Requirements	7
	Access Rights	8
2 – New Ins	tallation	9
Loca	al Installation	9
	Manual Installation	9
	Silent Installation	9
Netw	work Deployment	10
	Preparation	10
	Task Automation and Management Framework	11
	Powershell	11
	Deployment	11
0		
Con	figuration Files Management (CYME only)	12
Con 3 – Version	Upgrade	12 13
Con 3 – Version Clea	figuration Files Management (CYME only) Upgrade an Upgrade – Local Installation	12 13 13
Con 3 – Version Clea	figuration Files Management (CYME only) Upgrade an Upgrade – Local Installation Manual Installation	12 13 13
Con 3 – Version Clea	figuration Files Management (CYME only) Upgrade an Upgrade – Local Installation Manual Installation Silent Installation	12 13 13 13
Con 3 – Version Clea Clea	figuration Files Management (CYME only) Upgrade an Upgrade – Local Installation Manual Installation Silent Installation an Upgrade – Network Deployment	12 13 13 13 13 13 14
Con 3 – Version Clea	figuration Files Management (CYME only) Upgrade an Upgrade – Local Installation Manual Installation Silent Installation an Upgrade – Network Deployment Preparation.	12 13 13 13 13 14 14
Con 3 – Version Clea	figuration Files Management (CYME only) Upgrade an Upgrade – Local Installation Manual Installation Silent Installation an Upgrade – Network Deployment Preparation Task Automation and Management Framework	12 13 13 13 13 14 14 14
Con 3 – Version Clea	figuration Files Management (CYME only) Upgrade an Upgrade – Local Installation Manual Installation Silent Installation an Upgrade – Network Deployment Preparation Task Automation and Management Framework Powershell	12 13 13 13 13 14 14 15 15
Con 3 – Version Clea	figuration Files Management (CYME only) Upgrade an Upgrade – Local Installation Manual Installation Silent Installation an Upgrade – Network Deployment Preparation Task Automation and Management Framework Powershell Deployment	12 13 13 13 13 13 14 14 15 15 15
Con 3 – Version Clea Clea	figuration Files Management (CYME only) Upgrade an Upgrade – Local Installation Manual Installation Silent Installation an Upgrade – Network Deployment Preparation Task Automation and Management Framework Powershell Deployment rade – Configuration Files Management (CYME only)	12 13 13 13 13 13 14 14 15 15 15 15
Con 3 – Version Clea Clea Upg Side	figuration Files Management (CYME only) Upgrade an Upgrade – Local Installation Manual Installation Silent Installation an Upgrade – Network Deployment Preparation Task Automation and Management Framework Powershell Deployment rade – Configuration Files Management (CYME only) -by-side Installation – Local Installation	12 13 13 13 13 14 14 15 15 15 15 16 16
Con 3 – Version Clea Clea Upg Side Side	figuration Files Management (CYME only) Upgrade	12 13 13 13 13 14 14 14 15 15 15 16 16 16
Con 3 – Version Clea Clea Upg Side Side	Iguration Files Management (CYME only) Upgrade	12 13 13 13 13 13 14 14 14 15 15 15 16 16 16 16

Clean Upgrade – Local Installation	17
Manual Installation	17
Silent Installation	17
Clean Upgrade – Network Deployment	18
Preparation	18
Task Automation and Management Framework	19
Powershell	19
Deployment	19
Side-by-side Installation – Local Installation	20
Side-by-side Installation – Network Deployment	20
Configuration Files Management (CYME only)	20
5 – Uninstallation	21
5 – Uninstallation	21 21
5 – Uninstallation Local Uninstallation Manual Uninstallation	21 21 21
5 – Uninstallation Local Uninstallation Manual Uninstallation Silent Uninstallation	21 21 21 21
5 – Uninstallation Local Uninstallation Manual Uninstallation Silent Uninstallation Uninstallation via Network Deployment	21 21 21 21 21 21
5 – Uninstallation Local Uninstallation Manual Uninstallation Silent Uninstallation Uninstallation via Network Deployment Preparation.	21 21 21 21 21 22 22
5 – Uninstallation Local Uninstallation Manual Uninstallation Silent Uninstallation Uninstallation via Network Deployment Preparation Task Automation and Management Framework	21 21 21 21 21 22 22 22
5 – Uninstallation Local Uninstallation Manual Uninstallation Silent Uninstallation Uninstallation via Network Deployment Preparation Task Automation and Management Framework Powershell	21 21 21 21 21 21 21 21 21 21 21 21 21 21 21 21 21 21
5 – Uninstallation Local Uninstallation Manual Uninstallation Silent Uninstallation Uninstallation via Network Deployment Preparation Task Automation and Management Framework Powershell Deployment	21 22
5 – Uninstallation Local Uninstallation Manual Uninstallation Silent Uninstallation Uninstallation via Network Deployment Preparation Task Automation and Management Framework Powershell Deployment	21 22 22 22 22 22 22 22 22 22 22 23



1 – Introduction

This installation guide includes instructions for installation and uninstallation of the CYME Power Engineering software. It also contains instructions for upgrading a CYME version or revision, and how to manage configuration files.

This manual is applicable for the following software and versions:

- CYMCAP: Version 6.2
- CYME: Version 7.0, 7.1
- CYMGRD: Version 6.5

Recommended System Requirements

Hardware Requirements

The CYME software requires a computer using Microsoft Windows ® XP*, Vista, 7 or 8; or using Microsoft Server 2003 or 2008. The minimum hardware requirements are:

- Pentium IV-based computer
- A minimum of 1024 MB of extended memory
- 1 GB of hard disk space

*XP: as of latest updates available on April 8th, 2014.

Software Requirements

The Microsoft .NET Framework Version 2.0 is strongly recommended to be installed on the computer.



Access Rights

After the CYME software is installed successfully, please make sure the user has read access to the following folder:

• C:\ProgramData\CYME\Common Files

Please also make sure the user has at least read access right to the following folder:

• C:\ProgramData\CYME\License Manager

The following registry key requires full read and write access:

• HKEY_CURRENT_USER\Software\CYME\

For the CYME sofware only:

• For access rights relating to configuration files, please refer to the sections titled "Configuration File Management" of the respective chapters depending on the type of installation.

For the CYMCAP software only:

The CYMCAP installation folder requires full access rights (read/write) as a client user in order to work
properly. Every working directory that contains a CYMCAP database (CymcapData.MDB file) needs full
access rights as well.

For the CYMGRD software only:

• The CYMGRD software will use the *My Documents\Cyme folder* of the user. Please make sure this folder is granted full read and write access rights.



2 – New Installation

This section contains instructions on how to install the CYME software on a system which never had any CYME software installed previously.

The CYME software can be installed locally or via network deployment. The following sections will explain each of these methods.

Local Installation

There are two methods to install the software locally: manually or by silent installation (automatic). Installing manually allows the client to visualize the details of the installation and the end-user license agreement. The silent installation is a rapid way for those who feel comfortable to perform the installation without visualizing the details mentioned here above. If the software is to be installed on multiple computers, the silent installation would allow a more standardized installation on all computers.

Manual Installation

Run the installation package (downloaded from my.cyme.com or from the installation CD). The package includes the software and License Manager, which is a tool for the management of available module licenses that enable the software to run.

Silent Installation

To install the CYME software through a command line, follow the steps here below.

1. Generate a script file (*.iss) that can be used for future installation with the command line:

```
c:\cymeprogram.exe /r /f1"C:\Setup.iss" /p"password" /z"/NOPKU"
```

where:

```
/r = record mode
```

/f1 = location of the script file

/p = password of the package

 Once the script is recorded, it can be used to install the CYME program on any computer with the following command.

c:\cymeprogram.exe /s /f1"C:\Setup.iss" /p"password" /z"/NOPKU"

where:

/s = silent mode

/f1 = location of the script file generated in step 1

/p = password of the package

3. Run the following command on any computer:

C:\Program Files (x86)\CYME\Cicense Manager\haspdinst.exe -i -kp -nomsg

where:

C:\Program Files (x86)\CYME\CYME is the installation directory selected while generating the installation script (*.iss) in step 1.

Network Deployment

Silent Installation is the method to use for network deployment of the CYME software.

Preparation

To install the CYME software through a command line, follow the steps here below.

- 1. Choose a shared network drive with read access to everyone (example: <u>\\myserver\shared</u>).
- 2. Put the CYME installation package inside the shared network drive.
- 3. Generate a script file (*.iss) that can be used for future installation with the command line:

where:

/r = record mode

/f1 = location of the script file

/p = password of the package

4. Generate a batch file (*.bat) with command lines similar to the following example:

```
C:\Windows\Temp\Cyme\cymeprogram.exe /s /f1"C:\Windows\Temp\Cyme\Setup.iss"
/p"password /z"/NOPKU"
```

C:\Program Files (x86)\CYME\Cicense Manager\haspdinst.exe -i -kp -nomsg

where:

C:\Program Files (x86)\CYME\CYME is the installation directory selected while generating the installation script (*.iss) in the previous step (step 3).





Task Automation and Management Framework

Powershell

After performing the four steps in the Preparation section above, verify that a valid network administration account is available and the destination computers (i.e. those on which the software is to be installed) can receive remote Powershell commands.

Enable receiving remote Powershell commands on destination computers by running the following command on those computers:

"Enable-PSRemoting -force"

Deployment

To install the CYME software through a command line, follow the steps here below.

- 1. Log on as Network Administrator on any computer.
- 2. Open a PowerShell command prompt.
- 3. Run the following command to connect to the remote computer:

Enter-PSSession -ComputerName RemoteComputerName

where:

RemoteComputerName = enter the destination computer name

4. Copy the folder from the network shared drive to the destination computer with the following command:

Copy-item "\\myserver\shared" -container -recurse \\RemoteComputerName\C\$\Windows\Temp\Cyme

5. Run the following command to execute the installation:

```
Start-proccess CMD.exe -verb runas -wait -argumentlist "/C",
"C:\Windows\Temp\Cyme\name.bat"
```

where:

name.bat is the batch file created in step 4 of the Preparation section

6. Run the following command to validate the installation:

Invoke-Command -ScriptBlock {"C:\Program Files (x86)\CYME\CYME" | Get-ChildItem}

where:

C:\Program Files (x86)\CYME\CYME is the installation directory selected while generating the installation script (*.iss) in step 3 of the Preparation section

7. Run the following command to disconnect from the remote computer:

Exit-PSSession

Configuration Files Management (CYME only)

The Configuration Files are supporting files and working directories that are mandatory to the operation of the CYME software.

The installation process would automatically create a registry key as follow to set the path of the configuration files:

HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\CYME\CYME

If for a specific reason it is not possible to grant read and write access to HKEY_LOCAL_MACHINE, it is possible to create the following key to allow the software to use HKEY_CURRENT_USER instead (which normally has read and write access)

HKEY_CURRENT_USER\Software\Cyme\CONFIGURATION_FILES\

Once the key is created, add the DWORD value UseHKCU and set it to 1.

ile Edit View Favorites Help						
🔁 📙 Cyme	•	Name	Туре	Data		
E L CGR	and a	ConfigurationName71	REG_SZ	Default_v71		
COM		ationNameDev	REG_SZ	Default_vDEV		
E- L CONFIGURATION_FILES		ab CymeVersion	REG_SZ	7.1		
		SelectConfiguration71	REG_DWORD	0x00000001 (1)		
H- MultExpPos_50	-		REG_DWORD	0×00000000 (0)		
	•	•				

The default path to the configuration files is set to:C:\ProgramData\CYME\CYME\.

The path can be changed with a tool named CymConfig.exe available within the installation folder of the software, or via the **File > Preferences** menu within the CYME program. Access to the registry key is required for such change as mentioned in the paragraph here above.

When a setting is changed within the program, these configuration files are overwritten. If it is not desired for the user to change any setting, whether default or pre-defined, rights can be restricted to read only for the directory at which these files are stored. Otherwise, the user would need to have read and write access to the directory at which these files are stored.

These configuration files can be saved on a read-only shared network drive when it is desired for all users within the same company to have the same settings.



3 – Version Upgrade

This section contains instructions on how to perform a version upgrade.

It is possible to replace the old version with a newer version, or to have a side-by-side installation where both the old and new versions are installed. The following sections will explain each of these methods.

Clean Upgrade – Local Installation

There are two methods to install a software version: manually or by silent installation (automatic). Installing manually allows the client to visualize the details of the installation and the end-user license agreement. The silent installation is a rapid way for those who feel comfortable to perform the installation without visualizing the details mentioned here above. If the software is to be installed on multiple computers, the silent installation would allow a more standardized installation on all computers.

Manual Installation

First, uninstall the existing version. Please see Chapter 5 for more information.

Once the existing version is uninstalled, run the installation package (downloaded from my.cyme.com or from the installation CD). The package includes the software and License Manager, which is a tool for the management of available module licenses that enable the software to run.

Silent Installation

To install the CYME software through a command line, follow the steps here below.

1. Generate a script file (*.iss) that can be used for future installation with the command line:

c:\cymeprogram.exe /r /f1"C:\Setup.iss" /p"password" /z"/NOPKU"

where:

/r = record mode

/f1 = location of the script file

/p = password of the package

 Once the script is recorded, it can be used to install the CYME program on any computer with the following command:

c:\cymeprogram.exe /s /f1"C:\Setup.iss" /p"password" /z"/NOPKU"

where:

/s = silent mode

- /f1 = location of the script file generated in step 1
- /p = password of the package

3. Run the following command on any computer:

C:\Program Files (x86)\CYME\Cicense Manager\haspdinst.exe -i -kp -nomsg

where:

C:\Program Files (x86)\CYME\CYME is the installation directory selected while generating the installation script (*.iss) in step 1.

Please note that the script required for a version upgrade could be different from the script for clean installation explained in Chapter 2 – New Installation.

Clean Upgrade – Network Deployment

Silent Installation is the method to use for network deployment of the CYME software.

First, uninstall the existing version. Please see Chapter 5 – Uninstallation for more information.

Preparation

To install the CYME software through a command line, follow the steps here below.

- 1. Choose a shared network drive with read access to everyone (example: <u>\\myserver\shared</u>).
- 2. Put the CYME installation package inside the shared network drive.
- 3. Generate a script file (*.iss) that can be used for future installation with the command line:

\\myserver\shared\cymeprogram.exe /r /f1"\\myserver\shared\Setup.iss" /p"password"
/z"/NOPKU"

where:

- /r = record mode
- /f1 = location of the script file
- /p = password of the package
- 4. Generate a batch file (*.bat) with command lines similar to the following example:

C:\Windows\Temp\Cyme\cymeprogram.exe /s /f1"C:\Windows\Temp\Cyme\Setup.iss" /p"password /z"/NOPKU"

C:\Program Files (x86)\CYME\Cicense Manager\haspdinst.exe -i -kp -nomsg

where:

C:\Program Files (x86)\CYME\CYME is the installation directory selected while generating the installation script (*.iss) in the previous step (step 3).





Task Automation and Management Framework

Powershell

After performing the four steps in the Preparation section above, verify that a valid network administration account is available and the destination computers (i.e. those on which the software is to be installed) can receive remote Powershell commands.

Enable receiving remote Powershell commands on destination computers by running the following command on those computers:

"Enable-PSRemoting -force"

Deployment

To install the CYME software through a command line, follow the steps here below.

- 1. Log on as Network Administrator on any computer.
- 2. Open a PowerShell command prompt.
- 3. Run the following command to connect to the remote computer:

Enter-PSSession -ComputerName RemoteComputerName

where:

RemoteComputerName = enter the destination computer name

4. Copy the folder from the network shared drive to the destination computer with the following command:

Copy-item "\\myserver\shared" -container -recurse \\RemoteComputerName\C\$\Windows\Temp\Cyme

5. Run the following command to execute the installation:

```
Start-proccess CMD.exe -verb runas -wait -argumentlist "/C",
"C:\Windows\Temp\Cyme\name.bat"
```

where:

name.bat is the batch file created in step 4 of the above Preparation section.

6. Run the following command to validate the installation:

Invoke-Command -ScriptBlock {"C:\Program Files (x86)\CYME\CYME" | Get-ChildItem}

where:

C:\Program Files (x86)\CYME\CYME is the installation directory selected while generating the installation script (*.iss) in step 3 of the above Preparation section.

7. Run the following command to disconnect from the remote computer:

Exit-PSSession

Upgrade – Configuration Files Management (CYME only)

When performing a version upgrade, configuration files do not need to be set again as the registry keys are kept. New keys will be created for the new version automatically - the files from the existing version will be copied and renamed with an extension denoting the newer version number. This new set of configuration files will be associated to the newer version.

If the user has the write access to the registry, the above process is done at the installation.

Side-by-side Installation – Local Installation

There is no need to uninstall the previous version for side-by-side installation (meaning both versions are kept installed on the computer). However, the new version has to be installed in a different directory else than the existing one.

For the rest of the installation steps please refer to the section titled Clean Upgrade – Local Installation on page 13.

Side-by-side Installation – Network Deployment

There is no need to uninstall the previous version for side-by-side installation (meaning both versions are kept installed on the computer). However, the new version has to be installed in a different directory than the existing one.

For the rest of the installation steps please refer to the section titled Clean Upgrade – Network Deployment on page 14.

Side-by-side Installation – Configuration Files Management (CYME only)

When performing a side-by-side installation, configuration files do not need to be set again as the registry keys are kept. New keys will be created for the new version automatically - the files from the existing version will be copied and renamed with an extension denoting the newer version number. This new set of configuration files will be associated to the newer version.

If the user has the write access to the registry, the above process is done at the installation.



4 – Revision Upgrade

This section contains instructions on how to perform a revision upgrade.

It is possible to replace the old revision with a newer revision, or to have a side-by-side installation where both the old and new revisions are installed. The following sections will explain each of these methods.

Clean Upgrade – Local Installation

There are two methods to install a software revision: manually or by silent installation (automatic).

Installing manually allows the client to visualize the details of the installation and the end-user license agreement. The silent installation is a rapid way for those who feel comfortable to perform the installation without visualizing the details mentioned here above. If the software is to be installed on multiple computers, the silent installation would allow a more standardized installation on all computers.

Manual Installation

First, uninstall the existing revision. Please see Chapter 5 – Uninstallation for more information.

Once the existing revision is uninstalled, run the installation package (downloaded from <u>my.cyme.com</u> or from the installation CD). The package includes the software and License Manager, which is a tool for the management of available module licenses that enable the software to run.

Silent Installation

To install the CYME software through a command line, follow the steps here below.

1. Generate a script file (*.iss) that can be used for future installation with the command line:

```
c:\cymeprogram.exe /r /f1"C:\Setup.iss" /p"password" /z"/NOPKU"
```

where:

/r = record mode /f1 = location of the script file

/p = password of the package

2. Once the script is recorded, it can be used to install the CYME program on any computer with the following command:

```
c:\cymeprogram.exe /s /f1"C:\Setup.iss" /p"password" /z"/NOPKU"
```

where:

/s = silent mode

- /f1 = location of the script file generated in step 1
- /p = password of the package

3. Run the following command on any computer:

C:\Program Files (x86)\CYME\Cicense Manager\haspdinst.exe -i -kp -nomsg

where:

C:\Program Files (x86)\CYME\CYME is the installation directory selected while generating the installation script (*.iss) in step 1.

Please note that the script required for a revision upgrade could be different from the script for clean installation explained in Chapter 2 – New Installation.

Clean Upgrade – Network Deployment

Silent Installation is the method to use to for network deployment of the CYME software.

Preparation

To install the CYME software through a command line, follow the steps here below.

- 1. Choose a shared network drive with read access to everyone (example: <u>\\myserver\shared</u>).
- 2. Put the CYME installation package inside the shared network drive.
- 3. Generate a script file (*.iss) that can be used for future installation with the command line:

\\myserver\shared\cymeprogram.exe /r /f1"\\myserver\shared\Setup.iss" /p"password"
/z"/NOPKU"

where:

/r = record mode

/f1 = location of the script file

/p = password of the package

4. Generate a batch file (*.bat) with command lines similar to the following example:

```
C:\Windows\Temp\Cyme\cymeprogram.exe /s /f1"C:\Windows\Temp\Cyme\Setup.iss"
/p"password /z"/NOPKU"
```

```
C:\Program Files (x86)\CYME\Cicense Manager\haspdinst.exe -i -kp -nomsg
```

where:

C:\Program Files (x86)\CYME\CYME is the installation directory selected while generating the installation script (*.iss) in the previous step (step 3).





Task Automation and Management Framework

Powershell

After performing the four steps in the Preparation section above, verify that a valid network administration account is available and the destination computers (i.e. those on which the software is to be installed) can receive remote Powershell commands.

Enable receiving remote Powershell commands on destination computers by running the following command on those computers:

"Enable-PSRemoting -force"

Deployment

To install the CYME software through a command line, follow the steps here below.

- 1. Log on as Network Administrator on any computer.
- 2. Open a PowerShell command prompt.
- 3. Run the following command to connect to the remote computer:

Enter-PSSession -ComputerName RemoteComputerName

where:

RemoteComputerName = enter the destination computer name

4. Copy the folder from the network shared drive to the destination computer with the following command:

Copy-item "\\myserver\shared" -container -recurse \\RemoteComputerName\C\$\Windows\Temp\Cyme

5. Run the following command to execute the installation:

```
Start-proccess CMD.exe -verb runas -wait -argumentlist "/C",
"C:\Windows\Temp\Cyme\name.bat"
```

where:

where name.bat is the batch file created in step 4 of the Preparation section

6. Run the following command to validate the installation

Invoke-Command -ScriptBlock {"C:\Program Files (x86)\CYME\CYME" | Get-ChildItem}

where:

C:\Program Files (x86)\CYME\CYME is the installation directory selected while generating the installation script (*.iss) in step 3 of the Preparation section

7. Run the following command to disconnect from the remote computer:

Exit-PSSession

Side-by-side Installation – Local Installation

There is no need to uninstall the previous revision for side-by-side installation (meaning both revisions are kept installed on the computer). However, the new revision has to be installed in a different directory else than the existing one.

For the rest of the installation steps, please refer to the section titled Clean Upgrade – Local Installation on page 17.

Side-by-side Installation – Network Deployment

There is no need to uninstall the previous version for side-by-side installation (meaning both versions are kept installed on the computer). However, the new version has to be installed in a different directory than the existing one.

For the rest of the installation steps, please refer to the section titled Clean Upgrade – Network Deployment on page 18.

Configuration Files Management (CYME only)

When performing a revision upgrade, configuration files do not need to be set again as the registry keys are re-usable for any revision of the same version.



5 – Uninstallation

This section contains instructions on how to uninstall the CYME software.

The CYME software can be uninstalled locally or via network deployment. The following sections will explain each of these methods.

Local Uninstallation

There are two methods to uninstall the software: manually or by silent installation (automatic).

Manual Uninstallation

Run the installation package and follow the instructions on screen to uninstall the software. Another way to uninstall the CYME software is to use the *Uninstall or Change a Program* tool of Windows.

Here is an example from Windows 7:



Silent Uninstallation

To uninstall the CYME software through a command line, follow the steps here below. Please note that the following command lines must be run on a computer on which the CYME software was already installed.

1. Generate a script file (*.iss) that can be used for future uninstallation with the command line:

```
c:\cymeprogram.exe /r /f1"C:\Setup.iss" /p"password" /z"/NOPKU"
where:
/r = record mode
/f1 = location of the script file
/p = password of the package
```

2. Once the script is recorded, it can be used to install the CYME program on any computer with the following command:

```
c:\cymeprogram.exe /s /f1"C:\Setup.iss" /p"password" /z"/NOPKU"
```

where:

/s = silent mode

/f1 = location of the script file generated in step 1

/p = password of the package

Please note that the script required for uninstallation is different from the script for any installation methods explained in previous chapters.

Uninstallation via Network Deployment

Silent uninstallation is the method to use to for network deployment of the CYME software. Please note that the following command lines must be run on computers on which the CYME software was already installed.

Preparation

To uninstall the CYME software through a command line, follow the steps here below.

- 1. Choose a shared network drive with read access to everyone (example: <u>\\myserver\shared</u>).
- 2. Put the CYME installation package inside the shared network drive.
- 3. Generate a script file (*.iss) that can be used for future uninstallation with the command line:

```
\\myserver\shared\cymeprogram.exe /r /f1"\\myserver\shared\Setup.iss" /p"password"
/z"/NOPKU"
```

where:

- /r = record mode
- /f1 = location of the script file
- /p = password of the package
- 4. Generate a batch file (*.bat) with a command line similar to the following example:

```
C:\Windows\Temp\Cyme\cymeprogram.exe /s /f1"C:\Windows\Temp\Cyme\Setup.iss"
/p"password /z"/NOPKU"
```





Task Automation and Management Framework

Powershell

After performing the four steps in the Preparation section above, verify that a valid network administration account is available and the destination computers (i.e. those on which the software is to be installed) can receive remote Powershell commands.

Enable receiving remote Powershell commands on destination computers by running the following command on those computers:

"Enable-PSRemoting -force"

Deployment

To uninstall the CYME software through a command line, follow the steps here below.

- 1. Log on as Network Administrator on any computer.
- 2. Open a PowerShell command prompt.
- 3. Run the following command to connect to the remote computer:

Enter-PSSession -ComputerName RemoteComputerName

where:

RemoteComputerName = enter the destination computer name

4. Copy the folder from the network shared drive to the destination computer with the following command:

Copy-item "\\myserver\shared" -container -recurse \\RemoteComputerName\C\$\Windows\Temp\Cyme

5. Run the following command to execute the installation:

```
Start-proccess CMD.exe -verb runas -wait -argumentlist "/C",
"C:\Windows\Temp\Cyme\name.bat"
```

where:

name.bat is the batch file created in step 4 of the Preparation section.

6. Run the following command to validate the uninstallation:

Invoke-Command -ScriptBlock {"C:\Program Files (x86)\CYME\CYME" | Get-ChildItem}

where:

C:\Program Files (x86)\CYME\CYME is the installation directory selected while generating the installation script (*.iss) in step 3 of the Preparation section.

7. Run the following command to disconnect from the remote computer:

Exit-PSSession

Upgrade – Configuration Files Management (CYME only)...... 16

Index

1 – Introduction7
2 – New Installation
3 – Version Upgrade13
4 – Revision Upgrade17
5 – Uninstallation21
Access Rights
Clean Upgrade – Local Installation
Clean Upgrade - Network Deployment 14, 18
Configuration Files Management (CYME only)12, 20
Deployment
Hardware Requirements7
Local Installation
Local Uninstallation21
Manual Installation9, 13, 17
Manual Uninstallation21
Network Deployment10
Preparation10, 22
Recommended System Requirements
Side-by-side Installation – Configuration Files Management (CYME only)16
Side-by-side Installation - Local Installation 20
Side-by-side Installation – Network Deployment
Silent Installation9, 13, 17
Silent Uninstallation21
Software Requirements7
Task Automation and Management Framework11, 15, 19, 23